



SoftSeal Mask Fitting

It is important that the SoftSeal mask you select is the correct size to get the best seal to protect your respiratory system. Below are instructions for determining the most likely size of mask to fit your face. While this estimated size should reduce the number of masks you may need to try on, you still may find that the overall shape of your face is sealed better by a different size.

Have someone measure the distance between the bridge of your nose to the point just below your chin (See Figure 1). Select a mask suggested from the table.

Bridge to Chin (mm)	FilterMask+ or N95 Mask Size
78-98	Small
90-108	Medium
95-118	Large
99-130	X-Large

Bridge to Chin (mm)	VFold+ Mask Size
74-100	Small
82-110	Medium
97-130	Large
100-138	X-Large

